

Brodware

Floor mounted Bath Spout Installation Guide 1.8007.03.0.XX, 1.8107.03.0.XX, 1.9307.03.0.XX and 1.9707.03.0.XX Models

NOTE FOR INSTALLER

- Water proof up to the 1 / 2" BSP male thread water supply.
- To be installed by a licenced plumber.
- Ensure lines are flushed before fitment.

- 1) Install 1 / 2 " BSP male thread water supply 15mm above the finished floor level. Screw the base flange onto the 1 / 2 " BSP male thread. Apply thread sealant on the 1 / 2 " BSP male thread, and screw down the quick disconnect fitting.
- 2) Place cover plate over the base flange. Push spout down onto quick disconnect fitting, and secure with grub screw provided.
- 3) If the floor is not level, the adjustment screws in the fixing flange can be adjusted to ensure the spout is level.
- 4) Check for leaks and functionality.

